

Spider tent - user's manual



1. After unpacking the tent, put it on the ground.



2. Undo the zipper in each tent leg and put the weights inside. Then close the zipper.



3. Air starts to fill the tent. Remember not to cover the extractor fan.



4. Wait until the tent will stand on 4 legs.



5. Unpack the 4 sidewalls and zip them to the tent.



6. Now hammer the tent to the ground.



7. First, hammer the 4 tent legs with pegs to the ground.



8. Next hammer the sidewalls to the ground.



9. Tent is ready to use.



MITKO Sp. z o.o.

Osiedle 1 Maja 16G | PL 44-304 Wodzisław Śląski | TIN: PL 6470509572
Tel. +48 32 444 66 16 | Fax: +48 32 757 09 20 | office@mitkoforevents.com | www.mitkoforevents.com

MITKO Sp. z o.o. is registered with the District Court in Gliwice, X Commercial Division of the National Court Register.
TIN: PL 6470509572 | CRO: 270708422 | NCR: 0000331770. Share capital in the amount of PLN 200 000,00 fully paid-up.
The Company is represented by chairman Mr Michał Mitko.